



DIMMER CONTROL WIRING INSTRUCTIONS



MUST BE INSTALLED BY LICENCED ELECTRICIAN

